



**rainbow**  
professional  
shaping your environment



**rite**  
**edge**

# Welcome to an easier life...

Designed by landscape architects, our multi-award winning RITE-EDGE is increasingly specified in professional landscape designs as the obvious edge for lawns, borders, beds and pathways alike, keeping that pristine neat garden appearance with perfect straight, corners and enviable curves and shapes.

Held securely in place with barbed fixing stakes, RITE-EDGE is manufactured from an Aircraft Grade Aluminium Alloy designed to last at least 27 years, so no painting, staining, rusting or replacing to worry about. RITE EDGE, being light and easy to handle, comes in long lengths and has a unique, telescopic design to make installation very neat, quick and easy. The profile of RITE-EDGE features a smooth round top edge, so no sharp edges to cut you or damage the lawn mower blades, and a castellated body which gives maximum strength for heavy lawn mowers and prevents lifting by frost.

Stand back with pride and admire that permanent "Just-Edged" look without all those hours of back-breaking edging spade and shear work.



## Benefits...

- Permanent – no maintenance required
- Easy to install
- Saves hours of future edging work
- Keeps your garden at its best
- Many Border Options – Sand, Gravel, Lawn, Pebbles, Slate



# Technical Data & Installation

The RITE-EDGE is manufactured Aluminium Alloy 6063 to a T6 hardness whilst the fixing stakes are Aluminium Alloy 6061 to a T6 hardness. This is designed with a life expectancy of 27 years in a hot and humid environment such as Florida. We recommend 5cm (2") of overlap for each joint which should be considered in your length required calculation.

## Installation

1. Dig a small trench around 5cm wide and 10cm deep in the exact position you require your new edge.
2. Now form the RITE-EDGE to the shape and design you require including the 5cm overlap joints. This can now be placed into the trench you formed for the ledge.
3. Check the exact height for the top of the RITE-EDGE which should be just above true ground level but beneath the required cut grass level.
4. If you are now happy with the shape and the height, add the fixing stakes and drive fully home.
5. A simple back filling on the sides of your RITE-EDGE completes your RITE-EDGE installation.



## Colours Available:



# Product Specification

CODE	PRODUCT	PIECE LENGTH METRES	HEIGHT CM	THICKNESS MM	MIN RADIUS METRES	PACK QTY	PACK SIZE CM	PACK WEIGHT KG
C531	NATURAL ALUMINIUM EDGING	2.438	10.2	3	0.15	14	11.5x16.5x254	20.5
C531RT	NATURAL ALUMINIUM EDGING	1.2	10.2	3	0.15	4	5x11x124	3
C532	BROWN ALUMINIUM EDGING	2.438	10.2	3	0.15	14	11.5x16.5x254	20.5
C532RT	BROWN ALUMINIUM EDGING	1.2	10.2	3	0.15	4	5x11x124	3
C533	GREEN ALUMINIUM EDGING	2.438	10.2	3	0.15	14	11.5x16.5x254	20.5
C534	BLACK ALUMINIUM EDGING	2.438	10.2	3	0.15	14	11.5x16.5x254	20.5
C535	ALUMINIUM STAKES (COLOUR AS ABOVE)	2 PER LENGTH	30.5	3	-	28	20x7.5x31	3.2
C557	NATURAL HEAVY-DUTY RITE-EDGE	2.438	10.2	4.5	0.6	12	11.5x16.5x254	26.4
C560	NATURAL HEAVY-DUTY RITE-EDGE (14CM)	2.438	14	4.5	0.6	10	11.5x16.5x254	36.2

Distributed by:

